

USING THE WINLOG LITE SCADA SOFTWARE WITH A DT80-RANGE LOGGER

Winlog Lite SCADA software is a free package enabling a wide range of application development and online browser-based access. Factory and plant managers can benefit from using a dataTaker DT8X Series Data Logger to provide data to their Winlog Lite projects. WinLog software is one of the best free SCADA software applications available. It is useful for simple SCADA projects to more complex data visualizations projects. Here we will walk you through the configuration of the WinLog software with a dataTaker DT8x logger as the data source.

WINLOG WALKTHROUGH

1. Prerequisites:

- Apps Note: '[Connecting the DT8x to an Ethernet Modem.](#)'

2. Requirements:

- dataTaker DT8x datalogger running firmware V 7.12 or above
- PC with Winlog Lite installed (available from www.sielcosistemi.com)
- dataTaker DeTransfer software
- Network connection between the PC and the dataTaker

3. Method

3.1 Check dataTaker settings

Write down the dataTaker MODBUS_SERVER and ETHERNET profile settings. These contain the information that you'll need to communicate via Modbus RTU TCP. If you are using an automatic IP address, then you should consider changing this to a static IP address—consult your network administrator about this.

When using Modbus, the values are transmitted in integer (whole number) form. This means that the values are all rounded to the nearest whole number. To maintain decimal precision, you can specify a scale factor for the numbers transmitted over the Modbus connection, then divide the value on the receiving end. This is done via the SETMODBUS command.

To scale the dataTaker's channel variables 1-30 by 100 (which would give you 2 decimal places), you would enter the following dataTaker command:

```
SETMODBUS 1..30CV MBI 100
```

Note that when using the MBI format, the valid range is $-32768 + 32767$, hence if you use a divider of 100, then you must have values between $-327.68 + 327.67$.

3.2 Create and set up a Winlog Lite project

Open up the Winlog Lite 'Project Manager' by clicking **[Start]**

Programs

Winlog Lite




Project Manager

Click the **Create new project** button

Give the project a name Click **OK**

The project shall now appear in the project tree.

In the project tree, expand the project that you just created and click **Configuration** then double-click **Channels**.



In the Channels configuration window, select **Modbus RTU TCP** from the dropdown.

The Options window should now appear.

In the options window, change the Port number to the the value of the TCPIP_PORT parameter in your dataTaker and add the IP Address of your dataTaker to the IP address list.



Click **OK** to close the options window, then OK again to close the channels configuration window.

Double-click **Devices**.

Click **Add**, the New device dialog will appear.

Use the default Channel and Device settings (1,1) and enter a description for your device.

Click **OK** to close the dialog, then **OK** again to close the devices window.



3.3 Adding measurements (Gates) to the project:

In the project tree, click **Gates** then double-click **Numeric**.

The Gate builder window will appear.

To add or modify a gate, double-click on a blank or gate line.

This opens the **Gate properties** window.

On the **General** tab, the essential properties which must be defined include:

Gate ID Name your gate




N ID A number for your gate

Description

On the **Sampling** tab, choose the **Channel** and **Device** to be 1.

The **Address** is mapped to the channel variable you wish to view, but is 30,000 minus one (40,000 if you need to read/write). i.e. if you wish to view 23CV then you enter address 30022.

Change **Sample** to 'Always' and define your sample frequency.



On the **Value** tab, enter the **Maximum** and **Minimum** values for your variable



Change the **Variable Type** to S_WORD

Enter the number of **Decimal Digits** you will use (this is to counter the scaling performed when setting up the dataTaker)

On the **Conversion** tab, select 'Apply decimal digits conversion'. You may leave the rest of the fields as default.

Click **OK** to finish and add your gate.

Save the changes on the Gate builder window and close.




3.4 Creating a Template/Dashboard

In the project tree, click **Template**.

Right-click in the blank space and select **New File**.

A file with the name 'No Name' will appear.

Double-click the No Name file to open it.
The **Template Builder** window will appear.




In the template window you can choose a range of different controls and images to place on your dashboard.

Place the controls on the template, insert buttons, gauges, pictures, charts etc.

Remember to save the template as you build it up.

To assign variables to your controls, click on the **Gates** option in the property editor, on the left of the screen.

Follow the prompts to add your gates to the list.



Height	900
BkColor	192,192,192
Gates	idity.5.NUM,Rain_Accumulation,...
Drop function	

Once you have completed adding components to your dashboard, save your template and choose the template window.

3.5 Executing your template/dashboard

To run your dashboard, open the Project Manager and right-click on the project name and select Execute.

Once the project opens, click Supervision, Template, Template name.

If you would like a template to automatically open whenever you execute the project, you can follow this procedure:

First let us make the current project the default.

To do this, right-click on the project name and then click **Default**. Now the project will have a green border around its icon to indicate that it is the default project.

Now, the project can be executed from the start menu under:

[Start]

Winlog Lite



Runtime

In the project tree, click **Configuration Template**

The **Available Templates** list can be seen on the left. From this list, double-click the template you wish to open at startup.

This will transfer it to the **Selected Templates** list.

Click **OK**



For further information on the Winlog Lite SCADA Package with DT80-Range Data Loggers or for additional technical support, contact a CAS Data Logger Technical Specialist at (800) 956-4437 or www.DataLoggerInc.com.